








AFTER EVERY USE



DAILY







WEEKLY






The technical specifications, illustrations and dimensions contained in these instructions are given only as a guidance. They are not subject to any claim. The manufacturer reserves the right to make technical improvements to its equipment, without amending these instructions. For more information, please contact your representative.

MONTHLY



BI-MONTHLY



CLEANING PRODUCTS

4 x Coffee cleaning balls containers
Art. Nr. 101448

1 x Eversys cleaning set
Art. Nr. 105364

1 x 6 months cleaning kit
Art. Nr. 115333

1 x Dosing pump
Art. Nr. 102452

1 x Everclean 3 L
Art. Nr. 103013

12 x Everclean 1 L
Art. Nr. 107300

4 x Milk cleaning tabs containers
Art. Nr. 111066



Please scan this QR code and read the User Manual before using the appliance.

